Quantum State and Process Tomography with Entangled Photons

David Branning, Univ. Illinois, Urbana-Champaign

Paul Kwiat, J. Altepeter, E. Jeffrey, N. Peters, A. VanDevender

P. Goldbart, T.C. Wei

D. James (LANL), A. White (Univ. Queensland)









Optical Approaches to Quantum Information

The polarization of a photon comprises an ideal 2-state quantum system, equivalent to any other 2-state quantum system (e.g., two-level atom, spin-1/2, etc.), but often much easier to produce, manipulate, and detect.

- Quantum communication q. cryptography, dense coding, teleportation
- Quantum "network" coupling together remote quantum computers, multiparty protocols
- Small-scale quantum circuits algorithms, repeaters, DFS studies, simulating other systems
- Scalable quantum computing?

Current goals: • push the limits on control and measurement (error $< 10^{-4}$)


- develop a "benchmark technology"
- explore fundamentals of quantum info. processing.

Basic tools: arbitrary quantum state synthesis, precise process control, accurate q. tomography

Advanced tools: quantum storage, single-photon sources, entanglement-on-demand, etc.

Spontaneous Parametric Downconversion


Burnham & Weinberg, PRL 25, 84 (1970)



- *Energy conservation → energy entanglement
- †Momentum conservation → momentum entanglement

Type-I Phase-matching


(Photons have identical polarizations)




Single Qubit Generation


An arbitrary state:

$$\Box = \begin{bmatrix} A & B e^{\Box i \Box} \\ B e^{i \Box} & 1 \Box A \end{bmatrix}$$






Experiment vs. Theory



Two-crystal Source



$$|\psi\rangle = \frac{1}{\sqrt{2}} (|H\rangle_1 |H\rangle_2 + e^{i\varphi} |V\rangle_1 |V\rangle_2)$$

Maximally-entangled state


Arbitrary two-qubit pure states

- Via spontanous parametric downconversion (PDC), our experimental system can generate pure states of the form $\cos[|HH|] + \sin[e^{i\Box}|VV]$ where the two angles are tunable by waveplate settings before PDC
- We can obtain arbitrary states of the form alHH>+blHV>+clVH>+dlVV>, by preparing a state with appropriate [] and [] followed by a series of waveplates in both arms (i.e., local unitary transformations)
- Mathematically, given (a,b,c,d) (properly normalized), we can find ([], []) and local unitaries (U^A, U^B) such that $U_1 \quad U_2([],0,0,[])^T = (a,b,c,d)^T$
- Solution:

Arbitrary Two-qubit State Synthesis: Any Mixture/Purity (work in progress)

$$\begin{pmatrix}
A_{1} & A_{4} e^{i A_{5}} & \dots \\
A_{4} e^{-i A_{5}} & A_{2} & & \\
& & A_{3} & & \\
& & 1 - (A_{1} + A_{2} + A_{3})
\end{pmatrix}$$

15 free parameters $(A_1, A_2, ...)$



$$\theta_1 = f(A_1, A_2, \ldots)$$


Example: If we can set each of the parameters to one of 10 values, then we should be able to make 10^{15} states.

Quantum State Tomography

Measuring the density matrix for the 2-photon quantum system (c.f., measuring the Stokes parameters for a single photon)

$$\square_{\text{pure}} = |\square \square \square|$$

Example:
$$|\Box = (|HH\Box + |VV\Box)$$



Experimental Tomography

Single Photon - determine the Stokes parameters Measure contribution of H, V, D, R

Two Photon

Measure polarization correlations:

НН	HV	HD	HR
VH	VV	VD	VR
DH	DV	DD	DR
RH	RV	RD	RR


In principle, we can analytically extract the density matrix [] from these measurements.

In practice, statistical noise and setting uncertainties will typically lead to a ☐ with *negative* eigenvalues. ⊗

Solution: Use method of maximum likelihood to find the legitimate \square most consistent with the measured data.


[D. James et al. quant-ph/0103121]

2-qubit state creation & tomography



Computer Automated Tomography of 2-Qubit Polarization States

Black Box Generates arbitrary 2-Qubit States




Any 2-qubit tomography requires 16 of these measurements.

Examples


Arm 1	Arm 2
Н	V
Н	R
D	Γ

Manual (the old way)	Automated	Automated and Compensated (10 - 100x Brighter)	
		Ultra-Precise	Ultra-Fast
Manually set WP's for each measurement. (100 seconds each)	Computer sets WP's for all measurements. (100 seconds each)	Computer sets WP's for all measurements. (100 seconds each)	Computer sets WP's for all measurements. (10 seconds each)
60 minutes	30 minutes	30 minutes	3 minutes
Counting Error: 1.0 %	Counting Error: 1.0 %	Counting Error: 0.1 – 0.3 %	Counting Error: 0.3 – 1.0 %
WP Setting Error: 0.5 degrees	WP Setting Error: 0.001 degrees	WP Setting Error: 0.001 degrees	WP Setting Error: 0.001 degrees


2-Photon Quantum Tomography



From New System:



2-parameter characterization of 2-qubit states





White et al., PRA **65**, 012301 (2001)

Munro et al., PRA **64**, 030302 (2001)

Making MEMS:

Creation of MEMS 1: one decoherence will do







 \triangle n L << coherence length of pump

∧ n L >>coherence length of PDC pair

e.g., r=2/3, get you the 1/3 MEMS state


First MEMS:






$$F = 0.985$$

Beyond Werner States...




Adaptive Tomography



What is a quantum process?

A completely positive map, which converts an initial quantum state (possibly mixed) into a different quantum state, e.g. unitary transformations and decoherence.




How do we characterize one?

Quantum Process Tomography

Chuang & Nielsen, JMO 44, 2455 (1997); Poyatos, Cirac & Zoller, PRL 78, 390 (1997)


STANDARD




The ☐ → ☐ transforms allow us to reconstruct the unknown process.

ENTANGLEMENT-ASSISTED

(D'Ariano & Presti; Leung; Nielsen, Thew and White)




Single-Qubit & Entanglement Assisted Process Tomography




Single-qubit

Entanglement-assisted







Decoherer:




Partial polarizer:



<u><F></u>



98.7




Quantum Transducer

Convert photon quantum state from one wavelength to another


- •Capitalize on high-efficiency low-noise single-photon counters (Si APDs) from 500-800nm
- •Convert from (telecom) flying qubit to (atomic) storage qubit

Example:



Deterministic Single Photon Source

Classical (laser) source → Poisson photon number distribution




Number of photons

We wish to overcome this, yet retain controllable spectral characteristics

- Optical quantum computing and communication
- Quantum metrology
- Quantum cryptography

Experimental Design

We collect down-conversion from several pulses, and search for one that has exactly one pair, then store it in a delay cavity until the target time



→ single-photon output at regular intervals (~deterministic output from nondeterministic input!)

Target efficiencies

Compare to a classical pulsed laser

37% maximum probability of making one photon

18% probability of making two photons

Current technology

70% probability of making one photon

3% probability of making two photons

10 kHz rate

Stage 2 technology (multiple attempts method)

90% probability of making one photon

1.8% probability of making two photons

50 kHz rate

Future technology (more efficient detectors, lasers, electrooptics)


95% probability of making one photon


<1% probability of making two photons

10 MHz rate

Quantum Memory

In slow systems, the delay line may need to store photons for 1-50 \square s. Using a specially designed cavity, we can achieve this.





50 pass (300 ns) cavity

This can also be used as a quantum storage in other quantum information applications.

Summary

- High-fidelity synthesis of arbitrary single-qubit states
- Bright source of tunable 2-qubit states Even brighter source to come
- Automated quantum tomography
 Adaptive tomography still to come
- Filling the tangle-entropy plane -- MEMS Arbitrary states still to come
- Single qubit/entanglement-assisted process tomography Arbitrary process synthesis still to come
- Also in progress:
 Quantum transducer, Single photons, Quantum memory

Kwiat's Quantum Clan

